

Updating procedure for MAX T115+



Note: Before installing the latest version of firmware of MAX T 115+, please verify the serial number of your receiver.

- For receivers whose serial number is lower than *090110120000* please install file: **“O_MAXT115+.ssu”**
- For receivers whose serial number is higher than *090110120000* please install file: **“N_MAXT115+.ssu”**

In case of any doubt, please contact with sat@ftemaximal.com

Necessary material:

- USB 2.0 device or SD card (FAT 16).
- Last available software version.

To proceed with the upgrading, you must have the file with last available version, which you can download from: <http://www.ftemaximal.com/ingles/firmware.php>

From this website, you will reach a ZIP compressed file which must be decompressed in the root folder of the USB Memory device or SD card.

Once you have the update file in the root folder of your memory, please proceed to connect the memory or card at front connector of the receiver.


Select Menu / Setup / SW update and and press OK.



Press OK to access to menu Update by USB or Card reader




Press OK to access to window, which is showed on the side. We can select the updating file from the window on the right and press OK in order to start the updating.



iAttention! Do not power off receiver while updating is running.

When the bar arrives to the 100%, the receiver will reboot automatically.



In this moment the updating is complete.